Maintenance

Maintenance and Servicing

	i	i	
Part to maintain	Robot status	Checking frequency	Maintenance method
Drive wheels and auxiliary wheels	Powered off	1 week	Please wipe the surface with a clean cloth.
Trays	Powered off	1 week	Please wipe the surface with a clean cloth. If there are oil stains on the silicone pad, use clean water to wash and wipe it immediately.
Vision sensor, depth vision sensor, LiDAR and infrared gesture sensor	Powered off	1 week	Please use a clean cloth or lens cleaning tools to clean. In case of sudden contamination, be sure to handle immediately to avoid blocked sensors, which may lead to abnormal operation of the robot.
Robot body	Powered off	1 month	Please wipe the surface with a clean cloth.