




REFRIGERATOR

MODELS:

JBBFL30NMX00 (Panel Ready) (Left Hand)

JBBFR30NMX00 (Panel Ready) (Right Hand)

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11633286	Door, Refrigerator (RH Model)	28	W11633328	Condenser	59	W11633540	Drawer, Freezer (Small)
	W11633285	Door, Refrigerator (LH Model)	29	W11633329	Grille, Lower	60	W11633541	Drawer, Freezer (Large)
2	W11633290	Gasket, Refrigerator Door	30	W10805035	Drier (Service Drier Without Dye)	61	W11633545	Door, Freezer (RH Model)
3	W11633293	Bin, Door	31	W11633331	Tray, Defrost Drain		W11633544	Door, Freezer (LH Model)
4	W11125031	Housing, Water Filter	32	W11633333	Cord, Power	62	W11633546	Slide, Large Freezer Drawer (Left)
5	W11633296	Liner, Door Bin		W11633570	Harness, Compressor to EMC Filter	63	W11633547	Slide, Large Freezer Drawer (Right)
6	W11633301	Hinge, Door (RH Model)	33	W11633334	Buzzer	64	W11633548	Slide, Small Freezer Drawer (Left)
	W11633300	Hinge, Door (LH Model)	34	W11633336	Thermistor	65	W11633550	Slide, Small Freezer Drawer (Right)
7	W11633303	Support, Door Bin (Left)	35	W11633337	Evaporator, Refrigerator Compartment	66	W11633551	Fan, FC Evaporator
	W11685015	Support, Shelf	36	W11633498	Cover, Control Board	67	W11633552	Power Supply, LED (12W)
8	W11633306	Cap, Door Bin Support (Top Right/Bottom Left)	37	W11633499	Bumper, Door	68	W11633557	Support, Fill Tube Heater
9	W11633305	Cap, Door Bin Support (Top Left/Bottom Right)	38	W11633500	Power Supply, LED (16W)	69	W11633561	Compressor, Refrigerator Compartment (Includes Inverter)
10	W11633304	Support, Door Bin (Right)	39	W11633501	Control, Electronic	70	W11633563	Filter, EMC
11	W11633308	Air Duct, Upper	40	W11633502	Fan, RC Evaporator	71	W11633564	Regulator, Water Pressure
12	W11633309	Air Duct, Middle	41	W11633504	Grommet, Fan	72	W11633571	Light Strip, LED
	W11633567	Air Duct, Lower	42	W11633505	Reed Switch, Door	73	W11633574	Inverter, Refrigerator Compressor
13	W11633310	Interface, User	43	W11633506	Support, Crisper Cover	74	W11633575	Inverter, Freezer Compressor
14	W11633311	Panel, Ceiling	44	W11633507	Bracket, Lateral Mounting	75	W11633581	Hardware, Panel Installation
15	W11633315	Cover, Crisper	45	W11633508	Thumb Screw, Drawers To Slides	76	W11633582	Hardware, Anti-Tip
16	W11633316	Shelf, Glass	46	W11685016	Washer, Drawers To Slides	77	W11685017	Ladder, Shelf
17	W11633317	Drawer, Small Crisper	47	W11633509	Cut-Off, Thermal	78	W11685018	Grille, Top
18	W11633318	Drawer, Tall Crisper	48	W11633511	Pan, Ice	79	W11685019	Bracket, Top Grille (Right)
19	W11633319	Slide, Crisper Drawer (Left)	49	W11633513	Ice Maker		W11685020	Bracket, Top Grille (Left)
20	W11633320	Slide, Crisper Drawer (Right)	50	W11633514	Tube, Water Inlet			REFRIGERANT CHARGE
21	W11633321	Light, LED	51	W11633515	Valve, Water			Refrigerator 48 grams (R600a) Freezer 55 grams (R600a)
22	W11633322	Cover, Mounting Brackets	52	W11633516	Valve, Safety Water			
23	W11633323	Roller, Rear	53	W11633583	Kit, Filter Installation (Includes Water Filter, Filter Cap, 3/4" to 1/4" Adapter, Ice Scoop)			
24	W11633324	Roller, Front	54	W10680605	Filter, Water			
25	W11633325	Leg, Levelling	55	W11633535	Heater, Fill Tube			
26	W11633326	Compressor, Freezer Compartment (Includes Inverter)	56	W11633536	Evaporator, Freezer Compartment			
27	W11633327	Fan, Condenser	57	W11633537	Heater, Defrost			
			58	W11633538	Gasket, Freezer Door			

OPTIONAL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORY PARTS
		TOUCH-UP PAINT
	W10756744	Charcoal Sparkle (.6 oz Touch-up Bottle With Brush)
	W10756745	Charcoal Sparkle (.3 oz Touch-up Pen)
	W11644970	Handle Kit, Custom Panels (NOIR)
	W11644971	Handle Kit, Custom Panels (RISE)