




VERTICAL FREEZER

MODELS:

JBZFL18IGX10 (Panel Ready)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		Trim, Hinge	18	W10604160	Clip, Wire
	W11362247	Use and Care Guide		W10900024	Charcoal Sparkle	19	W10141645	Screw
	W10898660	Energy Guide	9	W11311927	Switch, Power Disconnect	20		Trim, Cabinet Side
	W11362249	Installation Instructions					W11111408	Ebony (Left Hand)
	W11362242	Tech Sheet	10	W10882791	Screw		W11111409	Ebony (Non-Hinge Side)
2		Cabinet (Not A Serviceable Part)	11	W10897082	Harness, Antenna	21	W10861217	Module, WIFI
3		Grille	12	W10678210	Screw (Black)	22		Assembly, Adjustable Toekick
	W10823623	Charcoal Sparkle	13	W11227357	Tube, Water (Also Order 2300868 - 5/16" Water Connector)		W10848725	Left Hand
4		Hinge, Top	14		Assembly, Grille Mount (Includes Nut)		W10848724	Right Hand
	W11240840	Charcoal Sparkle		W11028834	Left Hand	23	W11415331	Cover, Power Switch
5		Assembly, Roller Base		W11028835	Right Hand	24	W11356980	Cover, Safety Switch
	W10761654	Left Hand	15	W10895127	Cover, Hinge Bracket	25	W10759640	Panel, MC Rear
	W10761653	Right Hand	16		Hinge, Bottom	26	1157158	Screw
6	W10891495	Bracket, Hinge Attach		W11036483	Charcoal Sparkle			
7	W11560149	Switch, Light	17	W10141625	Screw			


FREEZER LINER AND ICEMAKER PARTS



FREEZER LINER AND ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10769486	Assembly, Fan	14	W10816928	Wall, False	35	2169104	Insulation, Sound Deadening
2	W10370680	Fitting, Drain	15	W10816934	Duct, Deli	36	W10895218	Cover, Evaporator Panel U Shape
3	W10816886	Cover, LED Side	16	W10916552	Gasket, Deli Duct	37	W10895214	Gasket, Evaporator Panel
4		Assembly, LED Strip	17	W10815187	Assembly, Duct	38	W11441792	Assembly, Evaporator Cover (Includes Insulation)
	W10826246	Left Hand	18	W10890824	Harness, Damper	39	W10780861	Cover, Evaporator Insulation
	W10901633	Right Hand	19	W11383505	Assembly, User Interface	40		Block, Evaporator Bypass
5	W11351164	Assembly, Evaporator and Heater	20	W10847990	Grille, Air Return		W11216532	Left Hand
		(Also Order the Following Lokring Parts)	21		Liner (Not A Serviceable Part)		W11216529	Right Hand
	W11504451	(3/1.8 NR MS 00) (Capillary Tube to Evaporator)	22	1157158	Screw	41	W10816944	Cover, Manifold
	W11506619	8 NK MS 00 (Suction Line to Evaporator)	23	W10816938	Assembly, Air Tower Panel	42		Crossbar, Control
6	W10225833	Grommet, Motor	24	W10903460	Light, LED		W10816922	Upper
7	12990511	Screw	25	W11224718	Screw		W10887667	Lower
8	W10816889	Cover, LED Top	26	W10909591	Assembly, Icemaker Wire (Includes Thermistor)	43	W11574922	Harness, Evaporator (Includes Thermistor)
9	W10826247	Strip, Top LED	27	W11391031	Assembly, Icemaker			
10	W10914639	Assembly, Light Strip	28		Cover, Icemaker			
11	W11176554	Assembly, Air Tower Gasket (Includes Air Tower)		W10880333	Black			
			29		Ladder, Shelf (Includes Screw Guide)			
				W10905671	Left Hand			
12	W10872906	Assembly, Duct Damper (Includes Heater)		W10905672	Right Hand			
			30	W11084854	Thermistor			
13		Assembly, Air Tower Bracket (Includes Rubber Rivets, Washers and Screws)	31	W10912104	Cover, Thermistor			
			32		Screw			
	W11036131	Upper		W11288606	Black			
	W11036132	Lower	33	W11312288	Heater, Defrost			
			34	W11365533	Assembly, Fill Tube (Includes Heater)			


FREEZER SHELF PARTS



FREEZER SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10824593	Assembly, Deli Shelf (Includes Thermistor)	7	W10816763	Assembly, Deli	13	W10875428	Assembly, Ice Bin
2	W11032681	Assembly, Shelf	8		Clip, Retainer	14	W11265008	Thermistor (Includes Cover)
3	W10824119	Assembly, Upper Crisper Slide Support		W10856559	Left Hand	15	W10914639	Assembly, Light Strip
4	W10821600	Assembly, Lower Crisper Slide Support		W10856558	Right Hand	16	W10903460	Light, LED
5	W10816844	Assembly, Crisper	9	W10824232	Assembly, Deli Slide Support	17	W11238953	Harness, Mullion
6	W10816832	Assembly, Ice Crisper	10	W10882791	Screw	18	W10902247	Plate, Crisper LED Support
			11	W10909589	Harness, Crisper LED	19	W11045476	Bracket, Support
			12	W10605575	Sidearm, Shelf			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10823677	Assembly, Freezer Door	6		Assembly, Panel Adjuster	10	W10895136	Cap, Panel Adjust Trim
2	W10824621	Assembly, Door Bin		W11215770	Horizontal			FOLLOWING PARTS NOT ILLUSTRATED
3		Gasket, Door		W11215289	Vertical			
	W11038430	Black	7	W11105109	Trim, Panel Adjust		W11028745	Gauge, Door
4	W10908496	Bracket, Air Divider	8	W11105107	Bracket, Panel Adjust			
5	W10908495	Divider, Air	9	W11085874	Screw			


UPPER UNIT PARTS



UPPER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Cover Plate	9	W10624574	Supply, Power	19	W11321592	Control, Electronic
	W10823654	Charcoal Sparkle	10	W11110768	Assembly, WIFI Module	20	W10909108	Control, Electronic (LED Driver)
2		Cap, Water Filter			(Also Order 2300868 - 5/16" Water Connector)	21	W10890820	Harness, HV
	W10813884	Grey				22	W10890821	Harness, LV
3	W10680605	Filter, Water				23	W10910459	Tray , Control Board Mounting
4	2223913	Clip	11	W11380825	Cord, Power	24	W10822213	Lid, Cover
5	W10873611	Harness, Valve (Also Order 2300868 - 5/16" Water Connector)	12	2203075	Spacer			
			13	W11168732	Screw			
6	W11248444	Latch, Push	14	W11040337	Assembly, Filter (Also Order 2300868 - 5/16" Water Connector)			
7	W11165806	Housing, Water Filter (Also Order 2300868 - 5/16" Water Connector)	15	W11050485	Tube, Filter Inlet			
			16	W10826558	Mount, Filter			
8	W10869169	Valve, Single Solenoid (Also Order 2300868 - 5/16" Water Connector)	17	W10826572	Cover, Filter Mount			
			18	W10882791	Screw			

LOWER UNIT AND TUBE PARTS



LOWER UNIT AND TUBE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11235263	Assembly, Compressor Cover	13	W11332037	Compressor (Also Order the Following Lokring Parts)	18	W11411189	Harness, Compressor
2	W10761666	Pan, Base				19	W10663674	Bracket, Inverter Mounting
3	W10141625	Screw				20	W10762098	Condenser (Includes Drain Pan Heater)
4	W10886557	Grommet, Evaporator Tray		W11504415	8.5/8 NR MS 00 (Suction Tube to Compressor)			(Also Order the Following Lokring Parts)
5	W11495450	Tube, Suction		W11504421	(8/5 NR MS 00) (High Pressure Side to Compressor)		W11504445	5/4 NR MS 00 (High Side to Condenser)
6	W10801047	Tray, Evaporator Drain		W11504416	8.5/6 NR MS 00 (Process Tube to Compressor)		W11506623	5 NK MS 00 (Suction Line to Condenser)
7	W10834246	Plate, Bottom						REFRIGERANT CHARGE
8	W11346984	Assembly, Inverter Box						37.4 grams (R600a)
9	W11297133	Tube, Discharge	14	W10587113	Grommet			
10	489473	Screw	15	2183042	Grommet			
11	W10801052	Assembly, Condenser Fan Shroud	16	W10805035	Drier (Service Drier Without Dye) (Also Order the Following Lokring Parts)			
12	W11517921	Tube, Process		W11504445	5/4 NR MS 00 (Heat Loop to Drier)			
				W11504447	5/1.8 NR MS 00 (Capillary Tube to Drier)			
			17	W10781987	Assembly, Drain Tube			

OPTIONAL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		BEZEL TRIM KIT
W11227384		Non Hinge - Left Hand / Hinge - Right Hand
W11227385		Hinge - Left Hand / Hinge - Right Hand
W11227386		Hinge - Left Hand / Non Hinge - Right Hand
		JOIN KIT
W11103738		Hinge - Left Hand / Non Hinge - Right Hand
W11103739		Non Hinge - Left Hand / Non Hinge - Right Hand
W11103740		Non Hinge - Left Hand / Hinge - Right Hand
		MISCELLANEOUS
212643		Sealer, Gum (4 Feet)
479502		Tape, Vinyl (3/4 x 108")
876370		Insulation (2 Pieces, 3" x 24" x 48")
876305		Insulation Kit (14 Pieces, 3" x 24" x 48")
876029		Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
978941		Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
505587		Sealer, Mastic (1 Qt)
503695		Cork, Sealer
20000008		Cleaner, Stainless Steel
542638		Grease, Silicone (1/2 Oz.)
542639		Cement, Alumilastic (1 1/4 Oz.)
833938		Kit, Terminal Connector
8003RP		Kit, Water Inlet
2300868		Connector, Water
		TORX SCREW WRENCH
1117510		Torx Key
		TOUCH-UP PAINT
W10756744		Charcoal Sparkle (.3 oz Touch-up Pen)
W10756745		Charcoal Sparkle (.6 oz Touch-up Bottle With Brush)