




Dishwasher

MODELS:

JDPSG244PS1 (Stainless)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	5		Access Panel	10		Toe Panel
	W11323304	Owners Manual		W11108979	Black		W11467733	Black
	W11366144	Tech Sheet	6		Panel, Front (Includes Item 11)	11	W10692757	Barrel Nut, Front Panel
	W11655300	Energy Guide		W11465871	Stainless	12	W11438978	Screw, Black
2		Arm, Hinge	7	3400000	Screw	13	W10189731	Screw
	W11662392	Left Hand	8	W11364953	Screw	14	W10919859	Insulation, Front Panel
	W11662370	Right Hand	9	W11038694	Insulation, Single Layer	15	W10919858	Insulation, Multi-Layer
3	W11377160	Cross Brace, Door						
4	W10829406	Pocket, Handle						


CONTROL PANEL AND INNER DOOR PARTS



CONTROL PANEL AND INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly	10	W11098822	Inner Door Assembly	18	W11397505	Fuse, In-line
	W11584731	Black	11	W11563231	Seal, Door Bottom	19	W11038734	Duct, Vent
2	W11336943	Jumper, Door	12	W11649432	Wiring Harness, Main (Includes Thermostat & Fuse)	20	W10348408	Screw
3	W11258418	Screw				21	W11448735	Jumper, Ground
4	W10711884	Screw (Long)	13	W11630924	Wiring Harness, Inner Door			
5	W11091934	Latch Assembly (Includes Switch)	14	W11092649	Dispenser Assembly			
6	W11673345	Control, Electronic	15	W11050927	Seal, Console/Door			
7	W11025634	Bezel, Vent	16	W11088985	Hanger, Control			
8	3400071	Screw	17	W11038720	Vent Assembly (Includes Fan)			
9	W10348409	Screw						


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11120458	Tub Assembly (includes gasket)	13	W11255994	Float Switch	24	W11362500	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
2	W11226744	Base, Terminal Box	14	W11184083	Plug, Tub			
3	W11035860	Gasket, Tub	15	W11429970	Water Inlet Assembly	25	W11393126	Sound Insulation, Bottom
4	W11429974	Nut, Water Inlet	16	W11455395	Leg, Leveling	26	W11536143	Heater Element Assembly
5	W11090487	Strike, Latch	17	3378128	Washer, Pronged Cup			
6	W11296374	Screw	18	3400014	Screw, Grounding	27	W11132441	Terminal Block
7	W11165091	Seal, Cabinet	19	3400892	Screw	28		Tub Mount, Third Level Rack
8	W11025993	Drip Tray	20	W11226746	Cover, Terminal Box			
9	W11025986	Funnel, Overfill Protection	21		Side Support, Tub		W11101573	Left Hand
10	W11025988	Funnel Extension		W10920122	Left Hand		W11256439	Right Hand
11	8269145	Bracket, Undercounter		W10920120	Right Hand	29	W10277003	Screw
12	W11165093	Cover, Tub Corner	22	W11221921	Shield, Tub Sound	30	W10920244	Nut, Tub
			23	W10919865	Insulation, U-Wrap			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11048807	Pump Assembly	10	W11243648	Motor & Sump Assembly	20	370445	Clamp, Hose
2	W11034554	Sump with Seal (Includes 3, 4, 5, 6 & 9)	11	W11036660	Isolator, Rear Motor	21	W11163419	Bracket, Thermostat
3	W10891543	Diffuser, Inlet	12	W11250985	Hose, Pressure	22	W11193089	Thermostat (Included with Main Wiring Harness)
4	W11050773	Drain Vent Assembly	13	W10900389	Hose, Suction	23	W11025970	Fill Valve Assembly
5	9741232	Screw	14	W11193157	Motor, Drain	24	W11122851	Clamp, Hose
6	W10891547	Check Valve, Drain	15	W11131184	Hose, Drain	25	W11036159	Hose
7	W11048456	Wash Arm Assembly	16	W11175571	Disc, Diverter	26	W11036143	Clip, Hose
8	371505	Clamp, Hose	17	W11497568	Bracket, Rear Motor	27	W10466656	Clamp, Hose
9		Diverter Valve Motor (Not Serviced)	18	W11418271	Fastener	28	W11036287	Hose, Inlet
			19	W11126174	Indicator, Optical Wash	29	W11236576	Clamp, Hose


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11507999	Feed Tube Assembly	5	W11128231	Cover, Diverter	7	W10891533	Filter
2	W11039888	Retainer	6	W10892836	Retainer, Docking (2nd Level)	8	W10891539	Screen
3	W11039869	Sprayarm, Third Level						
4	W11174340	Upper Sprayarm Assembly						


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10847873	Dishrack, Upper	5	W11373129	Handle, Dishrack Rear	9	W11179753	Clip, Pivot
2		Track, Assembly	6		Rack Adjuster	10	W11180178	Leveler, Adjuster Arm
	W11212732	Left Hand		W11180155	Left Hand	11	W11180176	Button, Adjuster Arm
	W11212734	Right Hand		W11180153	Right Hand	12	W11373133	Clip, Stemware
3	W11180605	Clip, Adjuster Arm	7	W11189985	Tine Row, Fold Down	13	W11170270	Screw
4	W11268684	Handle, Dishrack	8	W11179755	Positioner	14	9741232	Screw


LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11129939	Dishrack, Lower	5	W11267718	Lid, Silverware Basket	10	W11373129	Handle, Dishrack Rear
2	W11133746	Wheel & Transport Assembly	6	W10610895	Tine Row, Sliding	11	W11267722	Knife Holder
3	W11281130	Silverware Basket Assembly	7	W11268684	Handle, Dishrack	12	9741232	Screw
4	W11268661	Retainer, Sliding Tine Row	8	W10056351	Tinerow			
			9	W11268658	Retainer, Flex Row			

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11441109	Track, Dishrack	3	W11048219	Wheel	4	W11084874	Track Stop, Front
2	W11540175	Rack, Third Level				5	W11084872	Track Stop, Rear

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		DRAIN HOSE
	W10712310	12 Ft.
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)
	8171477	Floor Mount Kit
	8212560	Side Mount Kit