




GAS COOKTOP

MODELS:

JGD3536GB05 (Black)

JGD3536GS05 (Stainless)


COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	W10907868	Orifice (Left Front)	14	W10876259	Electrode (Left Front)
	W11125099	Use and Care Guide		W10849719	Orifice (5K) (Left Rear)		W10905489	Electrode (Left Rear)
	W11125095	Installation Instructions		W10907866	Orifice (Center Front)		W10876260	Electrode (Center Front)
	W11565420	Wiring Diagram		W10907867	Orifice (Center Rear)		W10876261	Electrode (Center Rear)
2		Top, Main		W10907865	Orifice (Right Rear)		W10876262	Electrode (Right Rear)
	W11373824	Black			Knob, Control	15		Bezel
	W11373823	Stainless	9	W11558935	Black		W10559486	Black
3	W10827923	Electrode, Spring		W11558934	Stainless		W10559494	Stainless
4	W10910375	Kit, Burner Cap			Grate Kit (Includes 4 Grates)	16	W11508237	Seal, Downdraft Pad
5	W10815355	Assembly, Burner (SR) (Left Front)	10		Black	17	W10814795	Bracket, Switch Mount
	W10815354	Assembly, Burner (AUX) (Left Rear)		W11241662	Black	18	7101P309-60	Screw
	W10815357	Assembly, Burner (UR) (Center Front & Right Rear)	11	W10826754	Holder, Orifice (10K) (Left Front)	19		Knob, Fan
				W10826751	Holder, Orifice (5k) (Left Rear)		W10559476	Black
	W10815356	Assembly, Burner (R) (Center Rear)		W10826753	Holder, Orifice (15K) (Center Front)		W10559475	Stainless
6	W10673618	Screw			Holder, Orifice (12.5K) (Center Rear)		FOLLOWING PARTS NOT ILLUSTRATED	
7	3400093	Screw		W10826752	Holder, Orifice (17K) (Right Rear)			
			12	W10866564	Switch, Blower		W11465122	Harness, Main
			13	4455917	Bracket, Cooktop Mounting		W11190478	Harness, Blower
							W11465762	Harness, Jumper
							7101P460-60	Screw, Grounding
							W10831977	Cord, Power
							W10132200	Relief, Strain
							W10183556	Clip, Wire
							W10909126	Kit, Plenum Screw
							W11022463	Kit, LP Orifice


BLOWER UNIT PARTS



BLOWER UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10836514	Assembly, Top Plenum	4	W10837737	Panel, Lower Plenum Access	7	7109P086-60	Washer
2	W10877782	Assembly, Downdraft Blower	5	W10815866	Filter, Grease	8	W11249635	Screw
3	W10837738	Assembly, Lower Plenum	6	7103P162-60	Nut, Lock			

BURNER BOX PARTS



BURNER BOX PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10235990	Tray, Spill	13	W11507167	Seal, Switch Shaft	21	W11511837	Valve
2		Box, Burner (Not Serviced)	14	W11537719	Harness, Switch			(Left Front & Center Rear)
3	W10258697	Cover, Blower Motor Harness	15	W11577790	Screw	22	W11511842	Valve
4	7101P426-60	Screw	16	W10827689	Assembly, Tube (Left Front)			(Left Rear)
5	W10811211	Bracket, Hat	17	W10827690	Assembly, Tube (Left Rear)	23	W11511836	Valve
6	W10894861	Cover, Spark	18	W10827691	Assembly, Tube (Center Front)			(Center Front & Right Rear)
7	W10475150	Module, Spark	19	W10827692	Assembly, Tube (Center Rear)	24	W11508234	Seal, Downdraft Shaft
8	W10361756	Fitting, Gas Supply	20	W10827693	Assembly, Tube (Right Rear)	25	W11249635	Screw
9	W11512352	Manifold Assembly				26		Tube, Manifold (Not Serviced)
10	3400804	Screw, Bracket						
11	W10949105	Bracket, Saddle Valve						
12	W10449143	Regulator, Pressure						

OPTIONAL PARTS (NOT INCLUDED)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		ACCESSORIES
	W11035422	Griddle
	W10620783	Kit, Ductless Downdraft Vent
	W10177003	Filter (Ductless)