




REFRIGERATOR

MODELS:

JUCFP242HX11 (Overlay)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W10204809	Screw	14	W11568794	Assembly, Switch Box
	W11467322	Energy Guide	7	W11580231	Defrost Holder and Heater	15	W11371097	Screw
	W10772894	Tech Sheet	8	W11568783	Switch, Case	16	W11580233	Kick Plate
	W11357308	Use and Care Guide	9	W11265587	Switch, Door	17	W11371095	Screw
2	W10774183	Screw	10	W11580229	Cover Assembly, Evaporator	18	4344763	Leg, Leveling
3	W11599889	Rail Assembly, Left Hand	11	W11312453	LED Assembly	19	W11580290	Assembly, Separator
4	W11599890	Rail Assembly, Right Hand	12	W11580230	Connector, Cover	20	W11312450	Cover, LED
5	W10621524	Screw	13		Cabinet (Not a Servicable Part)	21	W11359415	Fuse, Temperature


UPPER DRAWER PARTS



UPPER DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11599891	Drawer Box Assembly, Upper	8	W10204809	Screw	17	W11568842	Support, Lead Wire
2	W11568835	Mat, Upper Drawer	9	W10204810	Screw	18	W10204808	Screw
3	W11599884	Drawer Partition	10	W10204920	Nut	19	W11568841	Lamp Cover
4	W11360665	Gasket, Sash (Top/Bottom)	11	W11568838	Door Gasket, Short			FOLLOWING PARTS NOT ILLUSTRATED
5	W11568837	Gasket, Door	12	W11568839	Plate, Door Handle	W11599927		Assembly, Complete Door
6	W11580271	Top Foamed Door Assembly	13	W10204866	Screw, Handle	W11598387		Overlay Installation Kit
7	W10319183	Screw	14	W11312450	Cover, LED			
			15	W11599662	Control Panel Assembly			
			16	W11576360	Harness			


LOWER DRAWER PARTS



LOWER DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11599895	Drawer Box Assembly, Lower	6	W11580280	Door Assembly, Lower	12	W11568796	Plate, Push
2	W11568945	Mat, Lower Drawer	7	W10319183	Screw			FOLLOWING PARTS NOT ILLUSTRATED
3	W11599888	Drawer Partition	8	W10204809	Screw			
4	W11360665	Gasket, Sash (Top/Bottom)	9	W10204810	Screw		W11599969	Assembly, Complete Door
5	W11568947	Gasket	10	W10204920	Nut			
			11	W11568838	Door Gasket, Short			


UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11576947	Clamp, Cord	11	W10805035	Drier (Service Drier Without Dye)	20	W11498145	Cord, Power
2	W11371097	Screw				21	W11360592	Stopper
3	W11360241	Water Pan, Evaporator	12	W11265569	Clamp			REFRIGERANT CHARGE
4	W11375763	Screw	13	W11580235	Compressor			52 grams (R600a)
5	W11580234	Main PCB	14	W11580236	IB Box Assembly			
6	W11577175	Tag, Power Cord	15	W11580243	Cover, Panel			
7	4344826	Screw	16	W11360590	Cover, Side			
8	W11265570	Washer	17	W11360595	Compressor, Rubber			
9	W11313206	Cover, PCB	18	W11375771	Bolt			
10	W11360536	Assembly, Fan Motor	19	W11360596	Mount, Compressor			

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11580297	Icemaker	5	W11580305	Tube, Inlet	9	W11580302	Block, Filter
2	W11580299	Housing, Filter	6	W11580307	Tube, Water	10	W10281589	Tape, Filter
3	W11580300	Bracket, Filter	7	W11580309	Assembly, Water Valve	11	W10281560	Water Filter
4	W11580303	Tube, Water	8	W11580283	Bin, Ice	12	W11371345	Screw