




REFRIGERATOR

MODELS:

JUDFP242HX11 (Overlay)


CABINET PARTS



CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W11359416	Defrost Holder and Heater	15	W11371097	Screw
	W11467322	Energy Guide	8	W11568783	Switch, Case	16	W11239541	Grille
	W10772894	Tech Sheet	9	W11265587	Switch, Door	17	W11371095	Screw
	W11357308	Use and Care Guide	10	W11630433	Cover Assembly, Evaporator	18	4344763	Leg, Leveling
2	W10774183	Screw	11	W11568950	LED	19	W11568948	Assembly, Separator
3	W11599889	Rail Assembly, Left Hand	12	W11568787	Connector, Cover	20	W11312450	Cover, LED
4	W11599890	Rail Assembly, Right Hand	13		Cabinet (Not a Servicable Part)	21	W11359415	Fuse, Temperature
5	W10621524	Screw	14	W11568794	Assembly, Switch Box	22	W11568776	Cover Piece, Evaporator
6	W10204809	Screw				23	W11568786	Switch, Door
						24	W11568792	Assembly, Trim


UPPER DRAWER PARTS



UPPER DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11630376	Drawer Box Assembly, Upper	8	W10204809	Screw	17	W11568842	Support, Lead Wire
2	W11568835	Mat, Upper Drawer	9	W10204810	Screw	18	W10204808	Screw
3	W11599884	Drawer Partition	10	W11568934	Insulation, Door	19	W11568841	Lamp Cover
4	W11360665	Gasket, Sash (Top/Bottom)	11	W11568838	Door Gasket, Short	20	W10204920	Nut
5	W11568837	Gasket, Door	12	W11568839	Plate, Door Handle			FOLLOWING PARTS NOT ILLUSTRATED
6	W11568830	Top Foamed Door Assembly	13	W10204866	Screw, Handle	W11630413		Assembly, Complete Door
7	W10319183	Screw	14	W11312450	Cover, LED	W11598387		Overlay Installation Kit
			15	W11604678	Control Panel Assembly			
			16	W11576360	Harness			


LOWER DRAWER PARTS



LOWER DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11630379	Drawer Box Assembly, Lower	6	W11568937	Door Assembly, Lower	11	W11568838	Door Gasket, Short
2	W11568945	Mat, Lower Drawer	7	W10319183	Screw			FOLLOWING PARTS NOT ILLUSTRATED
3	W11630371	Drawer Partition	8	W10204809	Screw			
4	W11360665	Gasket, Sash (Top/Bottom)	9	W10204810	Screw		W11605925	Complete Door Assembly
5	W11568947	Gasket	10	W10204920	Nut			

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11576947	Clamp, Cord	11	W10805035	Drier (Service Drier Without Dye)	20	W11498145	Cord, Power
2	W11371097	Screw				21	W11360592	Stopper
3	W11360241	Water Pan, Evaporator	12	W11265569	Clamp	22	W11422771	PTC Thermistor
4	W11375763	Screw	13	W11531824	Compressor	23	W11568820	Cover
5	W11568810	Main PCB	14	W11568812	Protector, Motor			REFRIGERANT
6	W11577175	Tag, Power Cord	15	W11568821	Panel, Cover			CHARGE
7	4344826	Screw	16	W11360590	Cover, Side			52 grams (R600a)
8	W11265570	Washer	17	W11360595	Compressor, Rubber			
9	W11313206	Cover, PCB	18	4344780	Bolt, Compressor			
10	W11360536	Assembly, Fan Motor	19	W11360596	Mount, Compressor			