

SHARP®

Simply Better Living

works
with



SMC1469HS

SMC1469HS / SMC1469KS 1.4 CU.FT. SMART MICROWAVE

Alexa Command List

SMC1469HS / SMC1469KS ALEXA COMMANDS

Pair with your Amazon Alexa App and enjoy hands-free cooking with Alexa.

MENU ITEM	COMMAND	QUANTITY RANGE
+ 30 Seconds	Alexa, add 30 seconds to the microwave.	100% Power
Add Time	Alexa, add X minutes to the microwave. Alexa, add Y seconds to the microwave.	X = 01:00 – 60:00 Y = 00:01 - 00:59
Pause Time	Alexa, pause the microwave.	-
Resume Time	Alexa, resume the microwave.	-
Stop Time	Alexa, stop the microwave.	-
Time Cook	Alexa, microwave for X minutes and Y seconds. Alexa, cook for X minutes and Y seconds. Alexa, reheat for X minutes and Y seconds.	X = 01:00 - 60:00 Y = 00:01 - 00:59
Time Cook + Power Level	Alexa, microwave for X -minutes / Y -seconds at Z -power level. Alexa, cook for X minutes / Y seconds at Z power level.	X = 01:00 - 60:00 Y = 00:01 - 00:59 Z = 0 - 10 power level
Fish (Auto Defrost)	Alexa, defrost fish. Alexa, defrost X pounds of fish.	X = 8 / 16 / 24 / 32 oz
Meat (Auto Defrost)	Alexa, defrost meat. Alexa, defrost X pounds of meat.	X = 16 / 24 / 32 / 40 oz
Poultry (Auto Defrost)	Alexa, defrost poultry. Alexa, defrost X pounds of poultry.	X = 24 / 32 / 40 oz
Time Defrost	Alexa, defrost for X minutes. Alexa, defrost for Y seconds. Alexa, defrost for X minutes Y seconds	X = 01:00 - 60:00 Y = 00:01 - 00:59
Time Cook	Alexa, microwave for X minutes/seconds at power level Y . Alexa, cook for X minutes/seconds at power level Y .	X = 00:01 - 60:00 Y = 1 - 10
Beverage	Alexa, microwave beverage. Alexa, cook beverage. Alexa, microwave X cups of beverage. Alexa, cook X cups of beverage.	X = 1 / 2 / 3 cups
Reheat	Alexa, reheat dinner plate/leftover.	-
Popcorn	Alexa, microwave/cook popcorn. Alexa, microwave/cook mini popcorn. Alexa, microwave/cook classic popcorn. Alexa, microwave/cook X oz of popcorn.	Mini / Classic X = 1.16 / 3.3 oz

SMC1469HS / SMC1469KS ALEXA COMMANDS

MENU ITEM	COMMAND	QUANTITY RANGE
Potato	Alexa, microwave/cook potato(es). Alexa, reheat potato(es).	-
Fresh Vegetables	Alexa, microwave/cook fresh vegetables. Alexa, microwave/cook fresh veggies. Alexa, microwave/cook X oz of fresh vegetables. Alexa, microwave/cook X oz of fresh veggies.	X = 4 / 8 / 16 oz
Frozen Vegetables	Alexa, microwave/cook frozen vegetables. Alexa, microwave/cook frozen veggies. Alexa, microwave/cook X oz of frozen vegetables. Alexa, microwave/cook X oz of frozen veggies.	X = 4 / 8 / 16 oz
Melt/Soften - Butter	Alexa, melt/soften X oz of butter.	X = 3.5 / 7 oz
Melt/Soften - Cheese	Alexa, melt/soften X oz of cheese.	X = 1.75 / 3 oz
Melt/Soften - Chocolate	Alexa, melt/soften X oz of chocolate.	X = 7 / 10 oz
Melt/Soften - Ice Cream	Alexa, melt/soften X oz of ice cream.	X = 8 / 16 oz
Asparagus	Alexa, microwave/cook asparagus. Alexa, reheat asparagus.	-
Bacon	Alexa, microwave/cook bacon. Alexa, reheat bacon.	-
Beans	Alexa, microwave/cook beans. Alexa, reheat beans.	-
Beets	Alexa, microwave/cook beets. Alexa, reheat beets.	-
Breakfast Sandwich	Alexa, microwave/cook breakfast sandwich. Alexa, reheat breakfast sandwich.	-
Broccoli	Alexa, microwave/cook broccoli. Alexa, reheat broccoli.	-
Broccoli Cheddar Soup	Alexa, microwave/cook broccoli cheddar soup. Alexa, reheat broccoli cheddar soup.	-
Brownies	Alexa, microwave/cook brownies. Alexa, reheat brownies.	-
Brussels Sprout	Alexa, microwave/cook brussel sprouts. Alexa, reheat brussel sprouts.	-

SMC1469HS / SMC1469KS ALEXA COMMANDS

MENU ITEM	COMMAND	QUANTITY RANGE
Burgers - Turkey	Alexa, microwave/cook turkey burgers. Alexa, reheat turkey burgers.	-
Burgers - Salmon	Alexa, microwave/cook salmon burgers. Alexa, reheat salmon burgers.	-
Burgers - Veggie	Alexa, microwave/cook veggie burgers. Alexa, reheat veggie burgers.	-
Burrito	Alexa, microwave/cook burrito. Alexa, reheat burrito.	-
Butternut Squash	Alexa, microwave/cook butternut squash. Alexa, reheat butternut squash.	-
Cabbage	Alexa, microwave/cook cabbage. Alexa, reheat cabbage.	-
Carrots	Alexa, microwave/cook carrots. Alexa, reheat carrots.	-
Casserole	Alexa, microwave/cook casserole. Alexa, reheat casserole.	-
Cauliflower	Alexa, microwave/cook cauliflower. Alexa, reheat cauliflower.	-
Chicken	Alexa, microwave/cook chicken. Alexa, reheat chicken.	-
Chicken Noodle Soup	Alexa, microwave/cook chicken noodle soup. Alexa, reheat chicken noodle soup.	-
Chicken - Nuggets	Alexa, microwave/cook chicken nuggets. Alexa, reheat chicken nuggets.	-
Chicken - Tenders	Alexa, microwave/cook chicken tenders. Alexa, reheat chicken tenders.	-
Chicken - Wings	Alexa, microwave/cook chicken wings. Alexa, reheat chicken wings.	-
Chowder	Alexa, microwave/cook chowder. Alexa, reheat chowder.	-
Corn	Alexa, microwave/cook corn. Alexa, reheat corn.	-
Curly Fries	Alexa, microwave/cook curly fries. Alexa, reheat curly fries.	-
Dinner Plate	Alexa, microwave/cook dinner plate. Alexa, reheat dinner plate.	-
Dip	Alexa, microwave/cook dip. Alexa, reheat dip.	-

SMC1469HS / SMC1469KS ALEXA COMMANDS

MENU ITEM	COMMAND	QUANTITY RANGE
Dumplings	Alexa, microwave/cook dumplings. Alexa, reheat dumplings.	-
Edamame	Alexa, microwave/cook edamame. Alexa, reheat edamame.	-
Empanadas	Alexa, microwave/cook empanadas. Alexa, reheat empanadas.	-
Eggplant	Alexa, microwave/cook eggplant. Alexa, reheat eggplant.	-
Fish	Alexa, microwave/cook fish. Alexa, reheat fish.	-
Fish Sticks	Alexa, microwave/cook fish sticks. Alexa, reheat fish sticks.	-
French Fries	Alexa, microwave/cook french fries. Alexa, reheat french fries.	-
Frozen Edamame	Alexa, microwave/cook frozen edamame. Alexa, reheat frozen edamame.	-
Frozen Entrée	Alexa, microwave/cook frozen entrée. Alexa, reheat frozen entrée.	-
Frozen Pancakes	Alexa, microwave/cook frozen pancakes. Alexa, reheat frozen pancakes.	-
Frozen Pizza	Alexa, microwave/cook frozen pizza. Alexa, reheat frozen pizza.	-
Frozen Waffles	Alexa, microwave/cook frozen waffles. Alexa, reheat frozen waffles.	-
Hot Dog	Alexa, microwave/cook hot dog. Alexa, reheat hot dog.	-
Kale	Alexa, microwave/cook kale. Alexa, reheat kale.	-
Lasagna	Alexa, microwave/cook lasagna. Alexa, reheat lasagna.	-
Leftovers	Alexa, microwave/cook leftovers. Alexa, reheat leftovers.	-
Mac and Cheese	Alexa, microwave/cook mac and cheese. Alexa, reheat mac and cheese.	-
Meat	Alexa, microwave/cook meat. Alexa, reheat meat.	-
Meatballs	Alexa, microwave/cook meatballs. Alexa, reheat meatballs.	-

SMC1469HS / SMC1469KS ALEXA COMMANDS

MENU ITEM	COMMAND	QUANTITY RANGE
Meatballs - Chicken	Alexa, microwave/cook chicken meatballs. Alexa, reheat chicken meatballs.	-
Meatballs - Turkey	Alexa, microwave/cook turkey meatballs. Alexa, reheat turkey meatballs.	-
Mixed Vegetables	Alexa, microwave/cook mixed vegetables. Alexa, reheat mixed vegetables.	-
Mozzarella Sticks	Alexa, microwave/cook mozzarella sticks. Alexa, reheat mozzarella sticks.	-
Mushrooms	Alexa, microwave/cook mushrooms. Alexa, reheat mushrooms.	-
Nachos	Alexa, microwave/cook nachos. Alexa, reheat nachos.	-
Noodles	Alexa, microwave/cook noodles. Alexa, reheat noodles.	-
Oatmeal	Alexa, microwave/cook oatmeal. Alexa, reheat oatmeal.	-
Onion Rings	Alexa, microwave/cook onion rings. Alexa, reheat onion rings.	-
Onions	Alexa, microwave/cook onions. Alexa, reheat onions.	-
Pancakes	Alexa, microwave/cook pancakes. Alexa, reheat pancakes.	-
Parsnips	Alexa, microwave/cook parsnips. Alexa, reheat parsnips.	-
Pasta	Alexa, microwave/cook pasta. Alexa, reheat pasta.	-
Peas	Alexa, microwave/cook peas. Alexa, reheat peas.	-
Peppers	Alexa, microwave/cook peppers. Alexa, reheat peppers.	-
Pizza	Alexa, microwave/cook pizza. Alexa, reheat pizza.	-
Pizza Bagels	Alexa, microwave/cook pizza bagels. Alexa, reheat pizza bagels.	-
Pork Chops	Alexa, microwave/cook pork chops. Alexa, reheat pork chops.	-
Potato Wedges	Alexa, microwave/cook potato wedges. Alexa, reheat potato wedges.	-

SMC1469HS / SMC1469KS ALEXA COMMANDS

MENU ITEM	COMMAND	QUANTITY RANGE
Poultry	Alexa, microwave/cook X oz of poultry. Alexa, reheat X oz of poultry.	X = 24/32/40/48 oz
Quinoa	Alexa, microwave/cook quinoa. Alexa, reheat quinoa.	-
Rice - Brown	Alexa, microwave/cook brown rice. Alexa, reheat brown rice.	-
Rice - White	Alexa, microwave/cook white rice. Alexa, reheat white rice.	-
Salmon	Alexa, microwave/cook salmon. Alexa, reheat salmon.	-
Seafood	Alexa, microwave/cook seafood. Alexa, reheat seafood.	-
Shrimp	Alexa, microwave/cook shrimp. Alexa, reheat shrimp.	-
Soup	Alexa, microwave/cook soup. Alexa, reheat soup.	-
Spanakopita	Alexa, microwave/cook spanakopita. Alexa, reheat spanakopita.	-
Spinach	Alexa, microwave/cook spinach. Alexa, reheat spinach.	-
Spring Rolls	Alexa, microwave/cook spring rolls. Alexa, reheat spring rolls.	-
Squash	Alexa, microwave/cook squash. Alexa, reheat squash.	-
Steak	Alexa, microwave/cook steak. Alexa, reheat steak.	-
Stir Fry	Alexa, microwave/cook stir fry. Alexa, reheat stir fry.	-
Sweet Potato Fries	Alexa, microwave/cook sweet potato fries. Alexa, reheat sweet potato fries.	-
Sweet Potatoes	Alexa, microwave/cook sweet potatoes. Alexa, reheat sweet potatoes.	-
Taquitos	Alexa, microwave/cook taquitos. Alexa, reheat taquitos.	-
Tilapia	Alexa, microwave/cook tilapia. Alexa, reheat tilapia.	-
Tomato Sauce	Alexa, microwave/cook tomato sauce. Alexa, reheat tomato sauce.	-

SMC1469HS / SMC1469KS ALEXA COMMANDS

MENU ITEM	COMMAND	QUANTITY RANGE
Tomato Soup	Alexa, microwave/cook tomato soup. Alexa, reheat tomato soup.	-
Tomatoes	Alexa, microwave/cook tomatoes. Alexa, reheat tomatoes.	-
Tortellini	Alexa, microwave/cook tortellini. Alexa, reheat tortellini.	-
Tuna	Alexa, microwave/cook tuna. Alexa, reheat tuna.	-
Turnips	Alexa, microwave/cook turnips. Alexa, reheat turnips.	-
Vegetables	Alexa, microwave/cook vegetables. Alexa, reheat vegetables.	-
Waffles	Alexa, microwave/cook waffles. Alexa, reheat waffles.	-
Zucchini	Alexa, microwave/cook zucchini. Alexa, reheat zucchini.	-



Simply Better Living



A THRIVING ONLINE COMMUNITY



Simply Better Living is an online community that encourages a mindful lifestyle with Sharp home appliances through simple recipes and lifestyle tips. Our lifestyle blog sbl.sharppusa.com is dedicated to creative, ingenious solutions that make your life simpler, healthier, and better than ever before. Welcome home.

Start your free-forever, weekly subscription to [Simply Better Living Newsletter](#) today! Every week we share tips, recipes, life hacks and articles to help support and invigorate your healthy lifestyle.

The key to a simply better you is [Simply Better Living!](#) Come and see.

Amazon, Echo, Alexa, and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

© 2023 Sharp Electronics Corporation. All rights reserved.

Sharp and all related trademarks are trademarks or registered trademarks of Sharp Corporation and/or its affiliated companies. All other trademarks are property of their respective owners.

QUESTIONS?

1.800.BE.SHARP

SIMPLY BETTER LIVING

At Sharp Home Electronics Company of America, we are committed to Simply Better Living. Our innovative home appliance products are SIMPLE to use, BETTER than the competition, and encourage a HEALTHY LIFESTYLE.

SHARP ELECTRONICS CORPORATION
100 Paragon Drive, Montvale NJ, 07645
1.800.237.4277 • www.sharppusa.com



Be Original.