




15" GLASS ELECTRIC BUILT-IN COOKTOP

MODELS:

W5CE1522FB01 (Black)

COOKTOP PARTS



COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	10	3191049	Switch, Infinite (Front)	19	7101P309-60	Screw
	W10841974	Instructions, Installation		3191050	Switch, Infinite (Rear)			FOLLOWING PARTS NOT ILLUSTRATED
	W10840249	Guide, Use & Care	11	8273994	Element (1200W) (Front)	W11190493		Harness, Main
	3192609	Wiring Diagram		8273993	Element (1800W) (Rear)	3400015		Screw, Grounding
	8304571	Instructions, Undercounter	12	3193012	Light, Indicator	W11171891		Harness, Cooktop
2	W10840107	Cooktop	13	4455917	Bracket, Cooktop Mounting	3192439		Seal, Limiter
3	246119	Screw	14	3400093	Screw	98997		Clip
4	3192721	Rail, Element Support	15	7101P426-60	Screw	4455364		Bracket, Support
5	9759094	Spring, Locator	16	3183956	Seal, Switch Cover	8286642		Tape, Foam
6	W10414006	Bracket, Mounting	17	3192612	Lamp, Hot Surface Indicator			
7		Grommet	18	3196537	Screw			
	8285469	Black						
8	8286988	Box, Burner						
9	W10720680	Knob, Control						