




GAS COOKTOP

MODELS:

WCGK3030PS00 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8	W11352193	Flame Spreader (Left Front and Right Rear)	13	W10598131	Foot Pad, Grate (Outer)
	W11613935	Owner's Manual						
	W11635589	Quick Start Guide		W11352197	Flame Spreader (Left Rear)			FOLLOWING PARTS NOT ILLUSTRATED
2		Cooktop		W11352195	Flame Spreader (Right Front)		W11632720	Harness (Switch), Main
	W11600838	Stainless			Grommet		W10878749	Harness, Spark Module
3		Burner Cap Kit	9				3400015	Screw, Grounding
	W11395131	Black (Set of 4)		W10625915	Black		W10392003	Cord, Power
4		Grate Kit	10	W10758282	Screw		W10132200	Relief, Strain
	W11584879	Black (Set of 2)	11	W10723360	Orifice (Left Front)		313438	Clip, Harness
5	W10827923	Electrode, Spring		W11364991	Orifice (Left Rear)		W11573776	LP Conversion Kit
6		Knobs, Cooktop		W11631338	Orifice (Right Front)		3801F935-51	Bracket, Tie Down
	W11566380	Black		W11610057	Orifice (Right Rear)		7101P062-60	Screw (For Tie Down Bracket)
7	W11567145	Holder, Orifice (12K) (Left Front)	12	W11640975	Wiring, Electrode (440MM)			
	W11567151	Holder, Orifice (5K) (Left Rear)						
	W11567146	Holder, Orifice (9.1K) (Right Front)						
	W11567144	Holder, Orifice (18K) (Right Rear)						

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10743274	Screw	6	W11620860	Panel, Front	13	W11573974	Tube, Gas (Right Front)
2	W11573986	Manifold Assembly	7	W10449143	Regulator, Pressure	14	W11573971	Tube, Gas (Right Rear)
3	W11629615	Valve, Single (Left Front and Right Rear)	8	W11566469	Bracket, Orifice Holder	15	7101P426-60	Screw
	W11629616	Valve, Single (Left Rear)	9	W11349967	Module, Spark	16	W10443110	Screw
	W11629617	Valve, Single (Right Front)	10		Box, Burner (Not Serviced)	17	3196537	Screw
4	8287055	Bracket, Single Valve	11	W11573969	Tube, Gas (Left Front)	18	8286921	Screw, Burner Rail (M4)
5	W11507167	Seal, Switch Shaft	12	W11573970	Tube, Gas (Left Rear)			