

Whynter MultiCool Smart Control Enabled Portable Air Conditioners

Wireless Connection Instruction Manual

IMPORTANT NOTE

Read the manual carefully before installing or connecting your air conditioner. Make sure to save this manual for future reference.

www.whynter.com

Table of Contents

	PAGE
DECLARATION OF CONFORMITY	3
SPECIFICATION OF WIRELESS	3
MODULE PRECAUTIONS	3
SYSTEM OVERVIEW	3
DOWNLOAD AND INSTALL THE	4
APP CREATE YOUR ACCOUNT	4
NETWORK CONFIGURATION	5
HOW TO USE THE APP	8
SPECIAL FUNCTIONS	10

CAUTION

- This device complies with Part 15 of the FCC Rules and RSS 210 of Industry & Science Canada. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Only operate the device in accordance with the instructions supplied. This device complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC and IC radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult an experienced radio/TV technician for assistance.

DECLARATION OF CONFORMITY

We hereby declare that this air conditioner is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

SPECIFICATION OF WIRELESS MODULE

Model: OSK102 Standard: IEEE 802.11 b/g/n Antenna Type: External omnidirectional Antenna Frequency: 2.4 GHz (wireless) Maximum Transmitted Power: 15 dBm Max Dimensions: 41 x 24 x 5 (mm) Operation Temperature: 0°C ~ 45°C / 32°F ~ 113°F. Operation Humidity: 10% ~ 85% Power Input: DC 5V/300 mA

PRECAUTION

- 1. Supports operating systems: iOS 7+ or Android 4+.
- 2. In the event of an OS update, there may be a delay between the OS update and related software update during which your OS may or may not be supported until a new version is released. Your specific mobile phone or problems in your network may prevent the system from working; Whynter is not responsible for any incompatibility or network issues.
- 3. This air conditioner only supports WPA-PSK/WPA2-PSK (recommended) encryption.
- 4. To ensure proper scanning of the QR code, your smart phone must have at least a 5-megapixel camera.
- 5. Due to unstable network connectivity, requests may time out. If this happens, re-run the network configuration.
- 6. Due to unstable network connectivity, commands may time out. If this happens, the smartphone app and the actual product may display conflicting information. The information displayed on the actual product is always the most accurate available. Refresh the app to re-sync.

NOTE: Whynter is not responsible for any incompatibility, network issues, or problems with your wireless router and mobile phone.

SYSTEM OVERVIEW



Required devices for wireless operation:

- 1. Smartphone with compatible iOS or Android system
- 2. Wireless Router
- 3. Portable Air Conditioner / Mini Split System

DOWNLOAD AND INSTALL THE APP



Scan QR code

- 1. Open the Camera app of your smartphone
- 2. Select the rear facing camera
- 3. Hold your device and scan the QR code applicable to your smartphone's operating system
- 4. Your device will recognize the QR code and show a notification
- 5. Tap the notification to open the link associated with the QR code. You can also go to Google Play or App Store

and search for NetHome Plus App

6. Install the App to your device.

Note: All the images in this manual are for reference only, your product and app may look slightly different. The actual product and app instructions should be considered.

CREATE YOUR ACCOUNT

Make sure your smartphone is connected to your wireless router and your wireless router has a working internet connection. Follow these steps to create an account:





Enter your email address and desired password.

1. Choose "Create Account".

CREATE YOUR ACCOUNT

< Create Account			
johndoe@example.com			
****	7775		
****	775		
Password need 6~20 characters,must contain let and numbers.	ters		
Registration I have read and agree to the terms of service			

3. Mark the checkbox (Terms of Service) and press "Registration".

4. Check your email and activate your account by clicking the link provided.

NOTES:

- Make sure your smartphone is able to connect to the wireless network/router which will be used
- To avoid operation interruptions, make sure that the device is not connecting to other networks in range

NETWORK CONFIGURATION





- 1. Log in with your account.
- 2. Use the "+" in the top right to add device.





3. Select your Air Conditioner type.



4. Turn the air conditioner on, then wait for 5 seconds before continuing.



5. Press and hold the SWING button for 3 seconds. The unit will enter Access Point mode and the display will show "AP".

6. Go to your smartphone's wireless network settings, connect to the network named "net_ac_xxxx" and use the password "12345678".

NETWORK CONFIGURATION



7. Return to the app, select your preferred wireless network, and type in your password. Then press "Start Configuration".

<	Device Name	Save
Recommended N	lame:	
Living Room		~
Dining Room		
Kitchen		
Master bedroo	m	
Children bedro	oom	
Study		
Guest bedroor	n	
Storage room		
Custom Name:		
AirCon_806D	1	

9. Rename your air conditioner from the recommended name list or type your desired Custom Name.





10. The added air conditioner unit will be in the devices list upon login.

NOTES:

- When finishing network configuration, the app will indicate success by displaying a message.
- In unstable network connections, the air conditioner units may still appear on the app as "offline. If this happens, wait for itto show up on the device list or turn off the air conditioner. After 30 seconds, turn on the unit and wait a few minutes before checking again. If the unit is still offline, try the pairing process again.

HOW TO USE THE APP

1. BACK ARROW: Use this arrow to take you back to the main screen.

2. UNIT NAME: This is the name of the unit you are currently controlling.

3. FUNCTION: Access functions such as the timer and sleep curve.

4. OUTDOOR TEMPERATURE: This display shows the current temperature outdoors.

5. INDOOR TEMPERATURE: This display shows the current temperature indoors.

6. MODES: Select desired operation mode.

7. TEMPERATURE AND MODE DISPLAY: This display shows what temperature and mode the air conditioner is set to.

8. POWER: Press to turn on or off the air conditioner.

9.FAN SPEED: Switch between fan speeds.

10. EXPRESS RUN: With this function, specific settings (mode, temperature, fan speed) can then be programmed and accessed on the main device control screen. See page 11.



Schedules

11. SWING: Press the SWING button to activate auto-Swing mode. The horizontal air louvers will start moving up and down.

12. AIR DIRECTION: Press the AIR DIRECTION button to change the louver movement and set the desired up/down air flow direction. The louver changes 6°in angle for each press.

13.BOOST: Cool or heat your room quickly and effectively by operating at the maximum fan speed. NOTE: Boost function is only available in Cool and Heat mode for mini-split air conditioners.

14. SLEEP CURVE: Press to activate SLEEP CURVE mode on and off. See Page 10.

15. LED: Press to activate indoor unit light display. Press LED button again to turn off indoor unit light display.

16. SOUND: Press to turn on or off audible sound when key selections are made.

17. SCHEDULES: Manually set times for your device to change settings. See Page 11.

HOW TO USE THE APP





(only for ARC-1050XPH)

SPECIAL FUNCTIONS

Functions on this page include: Sleep Curve, Express Run, Check, and Schedules.

NOTE: Not all models display all functions. Please check your model's user manual for more details. If a function is not available, it will not be displayed on the function list in the app.

SLEEP CURVE

With this function, you can customize your air conditioner's settings for each hour that you are asleep. Scroll left and right to adjust up to 8 hours of the sleep curve.

< Function		< Sleep Curve	Confirm			
Express run setting	>	Custom				
Schedules	>	The default curve is recommended. However, if yo like to customize the sleep curve, then turn on the				
Sleep Curve	>	Slider.				
Check	>	86°F 84°F				
Units F	Ĵ	82°F 81°F				
About Device	>	79°F				
Shared QR code	>	75°F	~			
Delete	>	73°F 72°F				
		70°F				
		66°F				
		64°F 62°F				
		60°F Oh 1h 2h 3h 4h	5h			

CHECK FUNCTION (SELF DIAGNOSIS)

With this function, you can run a self-diagnosis. The app will show a report on key items and their status.



SCHEDULES

With this function, you can manually select what time you would like the air conditioner to turn on/off. Additionally, you can select which days you would like the timer to apply to.

< Function	<	Sche	dules	Confirm	<	Schedu	les	Confirm	<	Sche	edules	Confirm	< Repeat
Express run setting		24 H	12 H			24 H	12 H		(24 H	12 H		Monday
Schedules >	11				11								Tuesday
Sleep Curve >	12	58 59	AM		12	59	AM		12	59	AM		Wednesday
Check >	01	00	PM	On	01	00	PM	On	01	00	PM	On	_
Units F C	02	01		Off	02	01		Off	02	01		Off	Thursday
About Device					03								Friday
Shared QR code	Repeat		Or	nly Once >	Repeat		Or	ly Once >	Repeat		Or	Ily Once >	Saturday
Delete >	Settings		Cool 6:	2°F High >	a	Setting	gs		Settings		Cool 62	°F High ⇒	Sunday
	Label		Afterno	oon Cool 🗧	Mode	Temperat		Fan	Label		Afterno	ion Cool >	
					dry auto			edium					
					cool	62	°F	high					
					fan	63							
						64							

EXPRESS RUN SETTINGS

With this function, specific settings (mode, temperature, fan speed) can then be programmed and accessed on the main device control screen.

