


## FOR SERVICE TECHNICIAN'S USE ONLY


## Wiring Diagram

Do Not Remove Or Destroy

Caution: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.



## LEGEND



## BURNER RATINGS



COMPONENT	RF	LF	RR	LR	CTR F	CTR R
5" WC NATURAL BTUs	0	10000	17000	5000	15000	12500
10" WC PROPANE BTUs	0	9100	15000	4000	15000	10000
5" WC NATURAL Whs	0	2931	4983	1466	4397	3664
10" WC PROPANE Whs	0	2667	4397	1172	4397	2931

## À L'USAGE DU TECHNICIEN DE RÉPARATION UNIQUEMENT


## Schéma de câblage

Ne pas enlever ou détruire

Mise en garde : Lors de toute intervention sur les circuits, étiqueter chaque conducteur avant de le déconnecter. Une erreur lors du rebranchement pourrait susciter une situation dangereuse ou un fonctionnement incorrect. Vérifier le bon fonctionnement de l'appareil après l'intervention.



## LÉGENDE



## NOMINALE DU BRÛLEUR

COMPOSANTS	AvD	AvG	ArD	ArG	CTR	CTR
5 PO COLONNE D'EAU GAZ NATUREL BTUs	0	10000	17000	5000	15000	12500
10 PO COLONNE D'EAU GAZ PROPANE BTUs	0	9100	15000	4000	15000	10000
5 PO COLONNE D'EAU GAZ NATUREL Whs	0	2931	4983	1466	4397	3664
10 PO COLONNE D'EAU GAZ PROPANE Whs	0	2667	4397	1172	4397	2931